



10 CELLULAR CONFINEMENT
1 1/2" = 1'-0"

8 TRENCH DRAIN
1" = 1'-0"

3 UNIT PAVING ON GRADE
1 1/2" = 1'-0"

4 UNIT PAVING ON PLANTING MODULE
1 1/2" = 1'-0"

12 SLOPE REINFORCEMENT ADJACENT TO PAVING
3/4" = 1'-0"

13 AREA DRAIN BELOW ENTRY MAT
1 1/2" = 1'-0"

5 TYPICAL WALL FOOTING SUBGRADE
1/2" = 1'-0"

1 CONCRETE PAVING - PEDESTRIAN
1 1/2" = 1'-0"

6 CONCRETE JOINTING
1 1/2" = 1'-0"

2 AGGREGATE PAVING
1 1/2" = 1'-0"

7 CONCRETE PAVING - TOOLING
NTS

9 RUBBER MULCH
1" = 1'-0"

11 SLOPE REINFORCEMENT
3/4" = 1'-0"

NOTES:
1. COORDINATE RUBBER MULCH INSTALLATION W/ IRRIGATION.

NOTES:
1. INSTALL CONTROL JOINTS AT EQUAL INTERVALS OF 5'-0" UNLESS OTHERWISE INDICATED.
2. INSTALL EXPANSION JOINTS @ 20'-0" INTERVALS MAX., UNLESS OTHERWISE INDICATED, AND WHERE SLAB MEETS ANY ADJACENT STRUCTURE.
3. TOOL ALL EXPOSED EDGES W/ 1/4" RADIUS.
4. RECESS EXPANSION JOINTS 1/4" BELOW FINISH GRADE.
5. SAWCUT JOINTS ARE PROHIBITED.

NOTES:
1. REFER TO 6/L-401 FOR TYPICAL JOINT TYPES.
2. REFER TO 5/L-401 FOR TOOLING.

NOTES:
1. REFER TO L101, L102 FOR LOCATION OF AGGREGATE TYPE.
2. REFER TO L409 FOR PRODUCT INFORMATION.

NOTES:
1. CONSTRUCT AND COMPLETE ALL WORK ON SLOPES PRIOR TO PREPARING FLATTER AREAS. FILL SLOPE FROM BOTTOM UP.
2. DETAIL APPLIES TO ALL SLOPES 4:1 AND STEEPER.

NOTES:
1. SET TOP OF GRATE 1/8" BELOW ADJACENT PAVING.
2. REFER TO CIVIL PLANS FOR CONNECTIONS TO STORM DRAINAGE SYSTEM.

NOTES:
1. DRAIN IS CENTERED TO CONCRETE PAD UNDER ENTRY MAT.
2. SET GRATE 1/8" BELOW IMMEDIATELY ADJACENT FINISHED GRADE.
3. ORIENT DRAIN BODY ORTHOGONAL TO PAVING.
4. CONNECT TO STORM DRAINAGE SYSTEM; PROVIDE MINIMUM 2% POSITIVE DRAINAGE.

NOTES:
1. EDGE RESTRAINT: 2 1/2 x 4 x 3/16" GALVANIZED STEEL ANGLE, AFFIXED TO TOP OF SLAB W/ EXPANSION ANCHORS, MIN. 24" O.C.
2. FOR ALL CUTS, REPLICATE EDGE CONDITION OF UN CUT UNIT.
3. INSTALL CUT UNITS MIN. 10 UNITS FROM ENDS OF COURSE. CUT UNITS LESS THAN 1/2 PAVEMENT DIMENSION ARE PROHIBITED. REMOVE CUT UNIT AND 2 ADJACENT UNITS; INSTALL 3 EQUAL CUT UNITS.
4. FOR RADIAL COURSES, INSTALL SYMMETRICALLY CUT UNITS AT REGULAR INTERVALS. CUT EACH UNIT FOR SMALLER RADII AND AS DIRECTED BY ARCHITECT.

NOTES:
1. REFER TO 11/L-401 FOR MORE INFORMATION.

NOTES:
1. REFER TO 6/L-401 FOR TYPICAL JOINT TYPES.
2. REFER TO 5/L-401 FOR TOOLING.

NOTES:
1. REFER TO L101, L102 FOR LOCATION OF AGGREGATE TYPE.
2. REFER TO L409 FOR PRODUCT INFORMATION.

NOTES:
1. REFER TO L101, L102 FOR LOCATION OF AGGREGATE TYPE.
2. REFER TO L409 FOR PRODUCT INFORMATION.

NOTES:
1. REFER TO 11/L-401 FOR MORE INFORMATION.

NOTES:
1. SET TOP OF GRATE 1/8" BELOW ADJACENT PAVING.
2. REFER TO CIVIL PLANS FOR CONNECTIONS TO STORM DRAINAGE SYSTEM.

NOTES:
1. DRAIN IS CENTERED TO CONCRETE PAD UNDER ENTRY MAT.
2. SET GRATE 1/8" BELOW IMMEDIATELY ADJACENT FINISHED GRADE.
3. ORIENT DRAIN BODY ORTHOGONAL TO PAVING.
4. CONNECT TO STORM DRAINAGE SYSTEM; PROVIDE MINIMUM 2% POSITIVE DRAINAGE.

NOTES:
1. EDGE RESTRAINT: 2 1/2 x 4 x 3/16" GALVANIZED STEEL ANGLE, AFFIXED TO TOP OF SLAB W/ EXPANSION ANCHORS, MIN. 24" O.C.
2. FOR ALL CUTS, REPLICATE EDGE CONDITION OF UN CUT UNIT.
3. INSTALL CUT UNITS MIN. 10 UNITS FROM ENDS OF COURSE. CUT UNITS LESS THAN 1/2 PAVEMENT DIMENSION ARE PROHIBITED. REMOVE CUT UNIT AND 2 ADJACENT UNITS; INSTALL 3 EQUAL CUT UNITS.
4. FOR RADIAL COURSES, INSTALL SYMMETRICALLY CUT UNITS AT REGULAR INTERVALS. CUT EACH UNIT FOR SMALLER RADII AND AS DIRECTED BY ARCHITECT.

NOTES:
1. REFER TO 11/L-401 FOR MORE INFORMATION.

NOTES:
1. SET TOP OF GRATE 1/8" BELOW ADJACENT PAVING.
2. REFER TO CIVIL PLANS FOR CONNECTIONS TO STORM DRAINAGE SYSTEM.

NOTES:
1. DRAIN IS CENTERED TO CONCRETE PAD UNDER ENTRY MAT.
2. SET GRATE 1/8" BELOW IMMEDIATELY ADJACENT FINISHED GRADE.
3. ORIENT DRAIN BODY ORTHOGONAL TO PAVING.
4. CONNECT TO STORM DRAINAGE SYSTEM; PROVIDE MINIMUM 2% POSITIVE DRAINAGE.

NOTES:
1. EDGE RESTRAINT: 2 1/2 x 4 x 3/16" GALVANIZED STEEL ANGLE, AFFIXED TO TOP OF SLAB W/ EXPANSION ANCHORS, MIN. 24" O.C.
2. FOR ALL CUTS, REPLICATE EDGE CONDITION OF UN CUT UNIT.
3. INSTALL CUT UNITS MIN. 10 UNITS FROM ENDS OF COURSE. CUT UNITS LESS THAN 1/2 PAVEMENT DIMENSION ARE PROHIBITED. REMOVE CUT UNIT AND 2 ADJACENT UNITS; INSTALL 3 EQUAL CUT UNITS.
4. FOR RADIAL COURSES, INSTALL SYMMETRICALLY CUT UNITS AT REGULAR INTERVALS. CUT EACH UNIT FOR SMALLER RADII AND AS DIRECTED BY ARCHITECT.